



- 1** Fold the instruction sheet to the appropriate product height option. (460 mm Height, 540 mm Height, 620 mm Height)
- 2** Measure from bottom edge of cabinet and use template to mark holes with awl. (x14)
- 3** Attach both left and right metal plates to cabinet wall using supplied screws. (x6)
- 4** Release left and right tray runners from bracket.
- 5** Install the top runners with another 6 bracket screws. (x6)
- 6** Install top runner brackets. Makes click sound.
- 7** Install metal tray loosely with screws, allowing for adjustment. (x4)
- 8** Adjust metal tray position, tighten screws when parallel. Place mat on top.
- 9** Align lower runners flush under metal plates. Drill and screw lower runners. (x8)
- 10** Install metal brackets. Makes click sound.
- 11** Install plastic tray loosely with screws, allowing for adjustment. (x4)
- 12** Adjust plastic tray position, tighten screws when parallel.
- 13** Measure and mark the cabinet bottom and side edge on the door.
- 14** Use template to mark bracket holes on the door. (x4)
- 15** Screw door arms to cabinet using the slotted holes. (x4)
- 16** Adjust left and right 1 then tighten. Adjust vertical 2 and tilt 3.
- 17** Screw the front bracket to the door 1. Lock vertical and tilt adjustment 2. (x4)
- 18** Install screw covers.
- 19** Install bins. (TIP: To release brackets from the runners, click switch 1 on the sides of the brackets and slide out 2)